



Quick Installation Guide

Motorized COS CMO


1 Connect the Motorized COS to Power Supply Terminal




2 START Terminal Connection



3 Auxiliary Contact Terminal



4 Output Indicator Lamp Terminal



5 Contactor Automatis to Position '0'

